



58mm micro printer usage guide

- Driver installation
 1. Execute NuvPos58_Driver.exe to install driver for Windows operating system.
 2. Add a new printer form control panel



3. Select USB printer port



4. Select NUV 58mm PRINTER as shown in following figure.

